

MAP

KEYS & REMOTES

Programming instructions for KF373 & KF374

Key blade requires cutting by your local locksmith.

Key blade must be cut from key blade tip to remote head

Transponder requires programming with scan tool. Please contact your local Mitsubishi dealer or workshop to program transponder in MAP part no: KF373 & KF374.

REMOTE PROGRAMMING PROCEDURE:

1. Insert key into the ignition (leave in the Lock position).
2. Insert OBD Programmer in to the vehicles OBD2 port located beneath the dash.
3. Press the hazard lights switch 6 times rapidly.
If performed correctly, the door locks will cycle. You are now in learn mode.
4. Press the Lock button on new remote 4 times. *Door locks cycle when accepted.*
5. Repeat step 4 for any other remotes including old remotes.
6. Remove OBD Programmer from the vehicles OBD port and remove the key from the ignition to exit learn mode.



KF373



KF374



WARNING! This remote control contains a button/coin cell battery. It is a lithium button/coin cell battery. If swallowed or placed inside any part of the body, a lithium battery can cause severe or fatal injuries within 2 hours or less. The battery is hazardous and should be kept out of reach of children at all times whether new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or the New Zealand National Poisons Centre on 0800 764 766.