



Programming instructions for KF108

Mazda Tribute / Ford Escape

NOTE: All existing remotes must be present when performing the following procedure.

1. Close all doors
2. Turn ignition from OFF to ON 8 times within 10 seconds, with the 8th time ending in ON. The door locks will lock and unlock to confirm that you have entered programming mode.

NOTE: If the door locks do not cycle try turning the key from ACCESSORIES to ON 8 times. If they still do not cycle, your vehicle may not have keyless entry.

3. Within 8 seconds press any button on the first keyless remote to be programmed. Door locks will cycle to confirm programming. If you only have one remote then skip to step 5.
4. Within 8 seconds, press any button on the second keyless remote. Door locks will cycle again to confirm programming. Repeat step 4. For all other remotes.
5. Turn ignition to OFF. Locks will again cycle to indicate end of programming mode.
6. The programming is now completed.



WARNING! This remote control contains a button/coin cell battery. It is a lithium button/coin cell battery. If swallowed or placed inside any part of the body, a lithium battery can cause severe or fatal injuries within 2 hours or less. The battery is hazardous and should be kept out of reach of children at all times whether new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or the New Zealand National Poisons Centre on 0800 764 766.