

MAP

KEYS & REMOTES

Programming KF386

Remote keypad to suit

Mitsubishi Magna TH-TW and Mitsubishi Verada KH-KW 1998-2005

To program multiple remotes you will need to have all the remotes available for the car as you will need to relearn them all.

To enter programming mode, turn the ignition key between the ACC and IGN position 3 times within a 5 second period (ACC-IGN-ACC-IGN-ACC-IGN) and leave key in IGN position.

The hazard lamps will now flash once to indicate the car has entered programming mode. NB: At this point all existing remotes have been erased from memory

Within 5 seconds press either of the buttons on the remote that is being trained. The hazards lights will now flash to indicate the remote has been successfully matched. This process may be repeated for up to 4 remotes.

Once you have successfully programmed your remotes turn the ignition key to the OFF position and vehicle will exit learn mode. Check the function of all buttons on each remote.

Programming mode will be terminated due to one of the following reasons:

- The ignition is turned off
- More than 5 seconds has elapsed since the last valid remote match
- 4 remotes have been matched to the vehicle
- No correct data has been received within 10 seconds



WARNING! This remote control contains a button/coin cell battery. It is a lithium button/coin cell battery. If swallowed or placed inside any part of the body, a lithium battery can cause severe or fatal injuries within 2 hours or less. The battery is hazardous and should be kept out of reach of children at all times whether new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or the New Zealand National Poisons Centre on 0800 764 766.