

# MAP

## KEYS & REMOTES

### REMOTE PROGRAMMING INSTRUCTIONS

KF297



KF298



KF400



***Please read carefully before trying to program your new remote. Some steps need to be performed quickly in this procedure so having a clear understanding is beneficial.***

***KF297 + KF400 only: Transponder must be programmed using a scan tool.***

- 1. Sit in the vehicle with all doors closed.*
- 2. Lock doors with power door lock switch on driver's door. Ensure all doors lock.*
- 3. Within 10 seconds; Insert & remove a working key from ignition (approximately 6-8 times) until the doors unlock.*
- 4. VERY QUICKLY re-insert key it to ignition, turn to the 'On' position and re-lock the doors using the power door lock switch on the driver's door. If performed correctly, you are now in 'Learn mode'.*
- 5. Press unlock button on new remote transmitter. If programmed successfully the doors will unlock.*
- 6. Remove the key from the ignition & open and close the driver's door to exit 'Learn mode'. Complete.*

### **Tips**

**Step 2:** *If all doors lock but the driver's door remains unlocked – try using a different button.*

**Step 3:** *Try inserting the key hard in to the ignition and removing it out towards the vehicle's window.*



**WARNING!** This remote control contains a button/coin cell battery. It is a lithium button/coin cell battery. If swallowed or placed inside any part of the body, a lithium battery can cause severe or fatal injuries within 2 hours or less. The battery is hazardous and should be kept out of reach of children at all times whether new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or the New Zealand National Poisons Centre on 0800 764 766.