

MAP

KEYS & REMOTES

Programming instructions for KF318 / KF319

Before commencing, ensure all existing remotes are available as they may require re-programming during this procedure. Headlights must also be turned off.

Camry

1. Open the driver's door (all other doors must be closed).
2. Insert key into the ignition and cycle from ACC to ON position 3 times within 5 seconds. (ACC-ON, ACC-ON, ACC-ON) resting in the ON position. PROG will now appear in the clock display.
3. Press the button on the remote to be programmed, the hazard lights will flash once. Repeat above steps for any additional remotes to be matched. Ensure PROG still appears in the clock LCD display.

Avalon

1. Open the driver's door (all other doors must be closed).
2. Insert key into the ignition and cycle from OFF to ON position 3 times within 5 seconds. (ACC-ON, ACC-ON, ACC-ON) resting in the ON position. The Security LED will illuminate continuously for 5 seconds.
3. While the Security LED is illuminated, press a button on the remote control, the hazard lights will now flash.
4. Repeat above steps for any additional remotes to be matched. Ensure Security LED is still illuminated.

Once successfully completed, remove the key from the ignition and exit the vehicle.





WARNING! This remote control contains a button/coin cell battery. It is a lithium button/coin cell battery. If swallowed or placed inside any part of the body, a lithium battery can cause severe or fatal injuries within 2 hours or less. The battery is hazardous and should be kept out of reach of children at all times whether new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or the New Zealand National Poisons Centre on 0800 764 766.